

November 5, 2020

Request for common frame ground

Thank you very much for using ASTRODESING products. We would like to ask customers to use FG cable when using our product to prevent a damage.

1. Please use an outlet with a protective ground terminal. If you cannot use it, be sure to use the FG terminal for grounding.
2. "When connecting the signal generator to the device under development, please use the attached FG cable to make the ground between the devices the same. If the frame grounds are not common, it may cause an electric shock or equipment failure.

How to use FG cable

Before turning on the power, connect the frame ground of the signal generator to the frame ground of the connected device with an FG cable.

When disconnecting between devices, disconnect the FG cable after disconnecting the connection cable.

If you have any question, please feel free to contact ASTRODESIGN.

<https://www.astrodeshign.co.jp/english/contact.html>